TUNTURI®

GO 10

USER MANUAL.....04-13
KÄYTTÖOHJE.....14-23

WWW.TUNTURI.COM

It's easy to feel good!

Contents

IMPORTANT SAFETY 4
INSTRUCTIONS..... 4
ASSEMBLY..... 5
Power cord and grounding instructions 5
Safety tether key..... 6
CONSOLE..... 6
Major function keys:..... 6
Displays & operating ranges..... 7
WORKOUTS 8
About your health 8
About the exercise environment..... 8
About using the equipment..... 8
Beginning an exercise session 8
Finishing an exercise session..... 8
How to motivate yourself to continue.... 8
Heart rate..... 9
OPERATION & PROGRAMS..... 9
MAINTENANCE 9
Cleaning and lubricating the treadmill 10
Lubricate the running deck according to the following instructions: 10
Aligning the running belt 10
Align the belt according to the following instructions 10
Adjusting the belt tension 11
Malfunctions 11
Error codes 11
Protective circuit 11
MOVING AND STORAGE..... 12
TECHNICAL DATA 13
SISÄLTÖ 14
Profiles 24
Parts list..... 25
Exploded view 26

IMPORTANT SAFETY INSTRUCTIONS

This Owner's Manual is an essential part of your training equipment: read all instructions in this manual before you start using this appliance. The following precautions must always be followed:

WARNING

Never use extension cords between the treadmill and your wall outlet. The device's maximum power consumption is 10 A. Outlets with fluctuating voltage of more than 10 % may result in erratic performance or cause damage to treadmill electronics. Using electrical power other than that, which has been specified in this manual will ultimately void any warranty, implied or otherwise.

WARNING

TO REDUCE ANY RISK TO PERSONS:

- Keep hands clear of any moving parts. Never place hands, feet or any other objects into any opening or under the treadmill.
- Never leave the treadmill unattended when plugged in. Unplug from outlet when not in use, before putting on or taking off parts. To disconnect, turn all controls to the off position, then remove plug from outlet.
- Close supervision is necessary when the treadmill used by, on, or near children, invalids, or disabled persons.
- Use the treadmill only for its intended use as described in this manual. Do not use attachments not recommended by Tunturi.
- Before you start using the treadmill, make sure that it functions correctly in every way. Do not use a faulty device.
- Keep the cord away from heated surfaces.
- Treadmill must not be used outdoors. Treadmill tolerates an environment measuring +10°C to +35°C. Air humidity must never exceed 90 %.
- Do not attempt any servicing or adjustment other than those described in this manual. The given instructions must be followed carefully.
- Never operate this treadmill if it has a damaged cord or plug, if it has been dropped or damaged, or dropped into water. Return the treadmill to a service centre for repair.
- Never operate the appliance with the air opening blocked. Keep the air openings free of lint, hair, and the like.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- The device must not be used by persons weighing over 135 kg (300 lbs).
- The equipment has been designed for home use.Tunturi warranty applies only to defects and malfunctions in home use. Further information on warranty terms can be obtained from your national Tunturi distributor. Please note that the warranty terms may vary from one country to another.

SAVE THESE INSTRUCTIONS!

ASSEMBLY

As for the assembly of the device, we recommend two grown-up persons. Do not take the treadmill out of the box: use the packing material to cover the floor on the assembly site.

Before assembling the device, insure all parts are present:

- Frame
- Power cord
- Assembly kit: keep the assembly tools, as you may need them e.g. for adjusting the equipment

In case of problems contact your Tunturi dealer. The directions left, right, front and back are defined as seen from the exercising position. To avoid injury, you must fold up the deck prior to lifting the treadmill out of the box.
Locate the hardware bag and parts that are listed in the chart below.



Part #	Description	Q'ty
A	Main frame and console	1
B	Side cap	2
C	Screw	6
D	Washer	4
E	Washer	2
F	Screw	6
G	Allen key	1
H	Screwdriver	1
I	Safety key	1

Lift up the upright, then place the screws (C) and washers (D, E) inside holes at the bottom of the upright. Tighten them well.



Attach the side caps (B) with screws (F) at the bottom of the upright, and tighten them well.



POWER CORD AND GROUNDING INSTRUCTIONS

Plug the socket end of the power cord into the treadmill at the left front corner. Before connecting the device to a power source, make sure that local voltage matches that indicated on the type plate. The treadmill operates at 110 V or 230 V.

This treadmill must be grounded.
If it should malfunction or breakdown, grounding provides a path of least resistance for electrical current to reduce the risk of electrical shock.
This product is equipped with a cord having an equipment-grounded conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances. Do not use extension cables when connecting the equipment to the power source.

DANGER!
Improper connection of the equipment grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman, if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product - if it will not fit the outlet, have a proper outlet installed by a qualified electrician.



SAFETY TETHER KEY

The treadmill cannot be used if the tether key is not properly installed on the console; if the key is removed from its place, the treadmill will immediately stop. Place the safety tether key in its place on the console. Ensure that the clip of the safety tether key is properly attached to your clothing; as the cord tightens, make sure the clip does not detach itself from your clothing before the safety tether key disconnects from the console.

CONSOLE

SAFETY KEY:
The monitor and the treadmill can be operated only with the key attached on the SAFETY KEY button and both of the monitor and the treadmill stop as soon as the key is removed.

MAJOR FUNCTION KEYS:

INCLINE +:
- Increases the incline level in the range from 0 % to 10 % shown in the Pulse / Incline Display. Pressing once increases 1 %, speed up the increment by pressing and holding it for 2 seconds.
- Press this button to choose the program.

INCLINE –:
- Decreases the incline level in the range from 0 % to 10 % shown in the Pulse / Incline Display. Pressing once decreases 1 % and to speed up the decrement by pressing and holding it for 2 seconds.
- Press this button to choose the program.

START/STOP:
- Starts or stops the program.

Re-Start :
- If the Treadmill is stopped during use, the machine turns in pause mode. When the START button is pressed again, the treadmill will ramp-up the speed to where it was stopped. If the treadmill is stopped for 5 minutes or more, Power is lost and the treadmill will have to be re-started.

ENTER / SELECT:
- Press this button to confirm your desired program or setting value.
- Press to display time, incline, pulse, distance, calories, speed.

SPEED +:
- Increases the speed level in the range from 0.8 to 16.0 KPH (0.5 to 10 MPH). Pressing once increases 0.2KPH (0.1 MPH) and to speed up the increment by pressing and holding it for 2 seconds.
- Press this button to choose the program.

SPEED –:
- Decreases the speed level in the range from 0.8 to 16.0 KPH (0.5 to 10 MPH). Pressing once decreases 0.2 KPH (0.1 MPH) and to speed up the decrement by pressing and holding it for 2 seconds.
- Press this button to choose the program.

C. SPEED HOT KEYS:
3 Speed Hot Keys are set as 3, 6, 9 KPH / 3, 6, 9 MPH. For example, the speed changes from any speed to 9 KPH by pressing the Speed
Hot Key 9.

D. INCLINE HOT KEYS:
3 Incline Hot Keys are set as 3, 6, 9 %. For example, the incline level changes from any level to 6 % by pressing the Incline Hot Key 6.

E. SPEED QUICK-ACCESS KEYS:
- + : Same as Speed +.
- - : Same as Speed –.

F. INCLINE QUICK-ACCESS KEYS:
- + : Same as Incline +.
- - : Same as Incline –.

DISPLAYS & OPERATING RANGES

TIME:
Shows the exercising time with counting up or down. While the treadmill is not running and the safety key is on, it can be chosen by pressing ENTER / SELECT then adjusted by pressing + / - keys. The range of counting up is from 00:00 to 99:59 and 10:00 to 99:00 with counting down. While counting down to 00:00, the monitor will beep 12 times then the treadmill will stop.

SPEED:
Shows the speed that the treadmill is providing. It can be adjusted by pressing SPEED+ or SPEED- keys from 0.5 to 10 MPH or 0.8 to 16 KPH.

DISTANCE:
Shows the distance. The range is from 0.00 to 999 KM/ML.

CALORIES:
Shows the kcal. The range is from 0.00 to 9999 kcal.

PULSE:
Shows the pulse rate

INCLINE:
Shows the incline %

LED TRACK:
10 LED = 0.4 km / 0.25 miles.

Workouts

ABOUT YOUR HEALTH

- Before you start any training, consult a physician to check your state of health.
- If you experience nausea, dizziness or other abnormal symptoms while exercising, stop your workout at once and consult a physician.
- To avoid muscular pain and strain, begin and end each workout by stretching.

ABOUT THE EXERCISE ENVIRONMENT

- Make sure the exercise environment has adequate ventilation. To avoid catching cold, do not exercise in a draughty place.
- Place the treadmill on a firm, level surface. Allow 120 cm or 4 feet of clearance behind the treadmill and 60 cm or 2 feet on either side and in front of the treadmill.
- We recommend that the equipment is placed on a protective base.

ABOUT USING THE EQUIPMENT

- Always unplug the treadmill from the electrical outlet after each training session.
- Only one person may use the equipment at a time.
- Keep hands clear of any moving parts. Never place hands, feet or any other objects under the treadmill.
- Wear appropriate clothing and shoes when exercising. Make sure your shoelaces are properly tied. To avoid injury and unnecessary wear on your treadmill, be sure your shoes are free of any debris such as gravel and small pebbles.

BEGINNING AN EXERCISE SESSION

- To avoid muscular pain and strain, begin and end each workout by stretching.
- Stand on the landing rails to the left and right of the running belt. Do not stand on the running belt.
- Always hold the handrail for support when getting on or off the treadmill and when changing the speed during exercise. Do not jump off the running belt while it is moving!

If you experience nausea, dizziness or other abnormal symptoms while exercising, stop your workout at once and consult a physician.

FINISHING AN EXERCISE SESSION

- Never leave the safety tether key in the treadmill.
- Use the main power switch to turn the unit off.
- Unplug the electrical cord from the wall outlet and from the treadmill.
- If necessary clean the treadmill from sweat with a damp cloth. Do not use solvents.
- Store the electrical cord where it is clear from all pathways and out of childrens' reach.

HOW TO MOTIVATE YOURSELF TO CONTINUE

- In order to reach the goals you have set, you'll need to keep finding the motivation to continue so you achieve your ultimate goal: life-long health and a new quality of living.
- Set yourself realistic targets.
- Progress step-by-step according to your schedule.
- Keep a fitness diary and write down your progress.
- Change your way of exercising from time to time.
- Use your imagination.
- Learn self-discipline.
- One important aspect of your training is versatility. Varying your training uses different muscle groups and helps maintain motivation.

HEART RATE

No matter what your goal, you'll get the best results by training at the right level of effort, and the best measure is your own heart rate. First find your maximum heart rate i.e. where the rate doesn't increase with added effort. If you don't know your maximum heart rate, please use the following formula as a guide:

220 - age

The maximum varies from person to person. The maximum heart rate diminishes on average by one point per year. If you belong to one of thez risk groups mentioned earlier, ask a doctor to measure your maximum heart rate for you. We have defined three different heart-rate zones to help you with targeted training.

BEGINNER:
50-60 % of maximum heart rate
Also suitable for weight-watchers, convalescents and those who haven't exercised for a long time. Three sessions a week of at least a half-hour each is recommended. Regular exercise considerably improves beginners' respiratory and circulatory performance and you will quickly feel your improvement.

TRAINER:
60-70 % of maximum heart rate
Perfect for improving and maintaining fitness. Even reasonable effort develops the heart and lungs effectively, training for a minimum of 30 minutes at least three times a week. To improve your condition still further, increase either frequency or effort, but not both at the same time!

ACTIVE TRAINER:
70-80 % of maximum heart rate
Exercise at this level suits only the fittest and presupposes long-endurance workouts.

To measure your heart rate: please use both hands to gently hold the Hand Pulse Sensors. There are 2 sensors and 2 pieces of metal part each sensor. Each hand must gently hold both metal pieces to trigger the measuring. The pulse rate will show in the "PULSE / Incline" Display.

OPERATION & PROGRAMS

- Insert the Safety key.
- Press the POWER button. The monitor will turn on.
- Select program with the SELECT button.
- In the program PRO1 (Manual program), the program window will display a track view. In the program PRO2-8 (preset profile program), the program window will display a profile view. Press ENTER / SELECT to confirm your desired program.
- In the programs PRO1 & PRO2-8, press + / - buttons to set up your desired time to do the exercise. Press ENTER / SELECT to confirm your setting value. Press START to begin. In the PRO1 program, set the incline and speed manually. In PRO2-8, the incline and speed changes are automatic. You can set the speed and incline of each profile bar also manually during training.

MAINTENANCE

The equipment is safe to use only when periodically maintained and inspected for faults and wear.

CAUTION!
Do not attempt any servicing or adjustment other than those described in this manual. Any other servicing must be performed by an authorized service representative. Check the tightness of all fixing screws once a year. Do not overtighten.

CLEANING AND LUBRICATING THE TREADMILL

FAILURE TO LUBRICATE YOUR TREADMILL MAY INVALIDATE THE PRODUCT'S WARRANTY!

Wipe the treadmill surfaces, especially the handlebars and console from dust with a damp cloth or towel. Do not use solvents. Use a small vacuum nozzle to carefully vacuum around all visible components (belt, running deck, side rails etc.). Also keep the area near the treadmill clean. While in use, the treadmill gathers dust that may cause problems in the operation of the equipment. In average domestic use (a maximum of 60 minutes a day), you should check the lubrication once a month
However, lubricate the belt only if needed. In more demanding use, the lubrication needs be checked at shorter intervals. This is best done before you begin a training session. Check the lubrication as follows:

- Ensure the treadmill is powered off! Step on the treadmill belt .and stand steadily where you normally run on the belt.
- 2. Take hold of the horizontal handlebar and push the belt with your feet so that it slides back and forth. The belt should move softly and evenly, without a sound.
- 3. If you notice jerky movement or if the belt will not slide check for lubrication by sliding your hand under the belt.

LUBRICATE THE RUNNING DECK ACCORDING TO THE FOLLOWING INSTRUCTIONS:

- Attach the nozzle of the lubrication tube to the T-Lube S container.
- Lift the running deck and lock it.
- Position the nozzle between the belt and the board. Try to reach the spray as far into the center of the running deck as possible.
- Spray the lubricant for 2-3 seconds.
- Lower the running deck into its normal position. Use treadmill for your training session. Or allow the treadmill to run for at least 5 minutes.

NOTE!
Lubricate your treadmill only with T-Lube S silicon lubricant. Contact your local Tunturi distributor for further supplies of T-Lube or further information on lubrication and maintenance.

ALIGNING THE RUNNING BELT

Monitor belt tracking during exercise and make adjustments as needed. The belt should run in the center of the treadmill. Alignment is not usually needed, provided

- The treadmill is placed on an even, solid and horizontal surface and the belt is correctly tensioned
- The alignment of the belt is correct

It is, however, possible for the belt to be pushed to one side due to the user's running style (e.g. more weight on one foot). The alignment of the belt is adjusted by turning the two bolts at the back of the treadmill.

ALIGN THE BELT ACCORDING TO THE FOLLOWING INSTRUCTIONS

- Turn the power switch on and increase the treadmill's speed to 5 km/h (3 mph).
- If the belt drifts to the left, turn the left adjustment bolt 1/4 turn clockwise and the right adjustment bolt 1/8 turn anti-clockwise. If the belt drifts to the right, turn the right adjustment bolt 1/4 turn clockwise and the left adjustment bolt ¼ turn anti-clockwise.
- If the belt remains centered the adjustment is correct. If not, continue to make small adjustments as above until the belt is correctly aligned.
  If the belt is allowed run across to one side for long periods of time the

edges of the belt may be damaged and the treadmill may not continue to operate correctly. Any damage to the belt caused by the lack of necessary adjustment will not be covered by the warranty.

ADJUSTING THE BELT TENSION

The belt must be tensioned if it begins to slip on the rollers. In normal use, however, keep the belt as loose as possible! The belt tension is adjusted by turning the same screws as used for aligning the running belt. If turning the screws will not effect the belt tension, please contact your local Tunturi dealer.

- Increase the treadmill's speed to 5 km/h (3 mph).
- Turn both adjustment screws an equal amount, ¼turn clockwise.
- Try to slow the belt down by holding onto the handrails and braking as you walk (as if you were walking downhill). If the belt slips, turn another 1/4 turn and repeat the test. When braking heavily the belt may slip. If the belt keeps slipping despite repeated adjustments, please contact your local Tunturi dealer.

MALFUNCTIONS

NOTE!
Despite continuous quality control, defects and malfunctions caused by individual components may occur in the equipment. In most cases it's unnecessary to take the whole device in for repair, as it's usually sufficient to replace the defective part. Always give the model, serial number of your equipment and in case of malfunctions also conditions of use, nature of malfunction and any error code.

When you encounter unusual behavior from the treadmill, simply turn the power switch off, wait 1 minute and turn the power switch on to reset the treadmill. This should clear incidental errors and ready the treadmill for normal operation again. If after you have reset the treadmill by turning the power switch off and on again, and the treadmill is still not operational, contact your local Tunturi dealer for service.

If you require spare parts, always give the model, serial number of your equipment and the spare part number for the part you need. The spare part list is at the back of this manual. Use only spare parts mentioned in the spare part list.

ERROR CODES

The user interface will display information about operational faults.

E1: Speed sensor error.
Unplug the electrical cord from the wall outlet and from the treadmill, wait 1 minute and turn the power switch on again. If treadmill recovers to normal operation, you may continue to use the treadmill. Otherwise, call the dealer for service.

E6, E7: Lift motor error.
Unplug the electrical cord from the wall outlet and from the treadmill, wait 1 minute and turn the power switch on again. If treadmill recovers to normal operation, you may continue to use the treadmill.

PROTECTIVE CIRCUIT

The machine will shut off when the electricity load is above the machine's capacity. To restart the machine, please follow the procedure below:

- Unplug the power cord from the machine's socket.
- Push in the safety switch.
- Replug the power cord into the machine's socket.



NOTE!
DON'T PUSH IN THE SAFETY SWITCH BEFORE UNPLUGGING THE MACHINE'S POWER CORD.

If you leave the treadmill plugged in after turning off the console, there will still be current running to the console. This treadmill is equipped with a safety control program that will automatically shut down the machine after six hours of no use. In the event of an automatic shut down, please follow the procedure below to restart the treadmill: A. Unplug the power cord form the machine's socket. Replug the power cord cord into the machine's socket to restart the machine.

Moving and storage

Folding
After assembly is complete, you may fold the machine into the upright position for storage. To hold the machine, raise the desk until it locks into position.

NOTE!
Make sure you hear the click sound of the deck locking into position. This is to ensure the deck is locked in place and will not drop back down.



NOTE!
Make sure the treadmill's elevation is at 0% before folding the deck. If the elevation is not at 0%, folding will damage the mechanism.

Unfolding
Lightly kick the switch indicated in the middle of the shock absorb rod to fold down the frame deck.



NOTICE!
This vertical rod (shock) has a built-in safety unfolding feature to help lower the deck slowly.
Please make sure there are no children or other things under the deck when you lower it.

TO MOVE THE TREADMILL
Before moving the treadmill, be sure the power cord is unplugged from the wall and the treadmill. Fold up the running deck until it is locked and push the equipment on the transportation wheels.



NOTE!
Transport the treadmill with extreme caution over uneven surfaces, for example over a step. The treadmill should never be transported upstairs using the wheels over the steps, instead it must be carried. We recommend that you use a protective base when transporting the equipment.

NOTE!
The running belt needs to be realigned and centred after moving.
To prevent malfunctioning of the treadmill, store it in a dry place with as little temperature variation as possible, protected against dust. Always unplug the treadmill from the electrical outlet when not in use.

TECHNICAL DATA

Length	174 cm
(storage position)	93 cm
Height	132 cm
(storage position)	152 cm
Width	78 cm
Weight	67 kg
Running surface	43 x 137 cm
Speed	0.8-16 km/h
Incline range	0-10 %
Motor	2 HP

The Tunturi Run 10 treadmill meets the requirements of the EU's EMC Directives on electromagnetic compatibility (89/336/EEC) and electrical equipment designed for use within certain voltage limits (73/23/EEC). This product therefore carries the CE label.

The Tunturi Run 10 treadmill meets EN precision and safety standards (EN-957). Due to our continuous policy of product development, Tunturi New Fitness reserves the right to change specifications without notice.

CAUTION!
The instructions must be followed carefully in the assembly, use and maintenance of your equipment. The warranty does not cover damage due to negligence of the assembly, adjustment and maintenance instructions described herein. Changes or modifications not expressly approved by Tunturi will void the user's authority to operate the equipment!

WE WISH YOU MANY ENJOYABLE TRAININGS WITH YOUR NEW TUNTURI TRAINING PARTNER!

SISÄLTÖ

HUOMAUTUKSET JA 14
VAROITUKSET 14
ASENNUS 15
VERKKOJOHTO 16
TURVA-AVAIN 16
YLEISTÄ 16
HARJOITTELUSTA..... 16
HUOMIOITAVAA HARJOITTELUPAIKASTA..... 16
HUOMIOITAVAA LAITTEEN KÄYTÖSTÄ 16
HARJOITUKSEN ALOITTAMINEN..... 17
HARJOITUKSEN PÄÄTTÄMINEN 17
SYKE 17
MITTARI 18
PAINIKKEET..... 18
NÄYTÖT 19
HUOLTO..... 20
JUOKSUMATON PUHDISTUS JA HUOLTOVOITELU 20
MATON KESKITTÄMINEN..... 20
MATON KIREYDEN SÄÄTÖ 21
KÄYTTÖHÄIRIÖT..... 21
VIRHEILMOITUKSET..... 21
YLIVIRTASUOJA..... 21
KULJETUS JA..... 22
SÄILYTYS 22
TEKNISET TIEDOT..... 23

HUOMAUTUKSET JA VAROITUKSET

Tämä opas on olennainen osa kuntolaitettasi. Perehdy ohjeisiin huolellisesti ennen kuin asennat, käytät tai huollat kuntolaitettasi. Sinun tulee ehdottomasti säilyttää tämä opas, sillä jatkossa se opastaa Sinua niin kuntolaitteesi tehokkaaseen käyttöön kuin huoltoonkin. Muista aina noudattaa tämän oppaan ohjeita.

- Laitteen saa kytkeä vain maadoitettuun pistorasiaan. Älä käytä jatkojohtoja juoksumaton kytkennässä virtalähteeseen. Laitteen virrankulutus on enintään 10 A. Virtalähteet, joiden jännitevaihtelu on suurempi kuin 10 % voivat johtaa juoksumaton virheelliseen toimintaan tai vahingoittaa juoksumaton elektroniikkaa. Mikäli laite kytketään tässä ohjekirjassa annettujen ohjeiden vastaisesti, laitteen takuu raukeaa.
- Laitteen verkkojohto on varustettu maadoitetuilla liittimellä ja pistokkeella. Muutoksia pistorasiaan tai verkkojohdon pistokkeisiin saa tehdä vain henkilö, jolla on lupa suorittaa sähkömekaanisten laitteiden huolto- ja korjaustöitä.
- Ennen harjoittelun aloittamista käy varmistuttamassa terveydentilasi lääkärillä.
- Älä yritä tehdä laitteelle muita kuin tässä ohjekirjassa kuvattuja säätöjä tai huoltotoimenpiteitä. Asennus- ja huoltotöitä tehtäessä virran on oltava kytkettynä pois ja verkkopistokkeen on oltava irti pistorasiasta.
- Laitetta saa käyttää vain sisätiloissa. Harjoitteluolosuhteissa laite kestää lämpötiloja +10 asteesta +35 asteeseen, varastoitaessa lämpötiloja –15 asteesta +40 asteeseen. Ilman kosteus ei saa missään tapauksessa ylittää 90 %.
- Laitteen ehdoton enimmäiskäyttäjäpaino on 135 kg.
- Laite on sallittu kotikäyttöön. Tarkempia tietoja kuntolaitteesi

takuusta saat Tunturi-laitteiden maahantuojalta. Huomaa, että takuuehdot voivat vaihdella maittain. Huomaa myös, ettei takuu korvaa mitään vahinkoja, jotka ovat aiheutuneet tässä ohjekirjassa mainittujen asennus-, säätö- ja huoltoohjeiden laiminlyönneistä.

ASENNUS

Suosittelemme, että laitteen asentaa kaksi aikuista henkilöä. Älä siirrä juoksumattoa pois pakkauksesta: kokoa laite käyttämällä laitepakkausta asennusalustana.

Varmista ennen laitteen asennusta, että seuraavat osat löytyvät pakkauksesta:

- Runko
- Virtajohto
- Asennustarvikesarja. Säästä

asennustarvikkeet, sillä voit tarvita niitä mm. laitteen säätämiseen.
Ota ongelmatilanteissa yhteys laitteen myyjään. Ohjeessa mainitut suunnat oikea, vasen, etu ja taka on määritelty harjoitusasennosta katsottuna.
Vaaratilanteiden välttämiseksi juoksualusta tulee nostaa ylös säilytysasentoon ennen juoksumaton nostoa pois kuljetuspakkauksesta.

Ota asennustarvikesarja kuljetuspakkauksesta.



Osa#	Kuvaus	Määrä
A	Runko ja mittari	1
B	Sivukate	2
C	Ruuvi	6
D	Aluslaatta	4
E	Aluslaatta	2
F	Ruuvi	6
G	Kuusiokoloavain	1
H	Ruuviavain	1
I	Turva-avain	1

Nosta käsituet ylös ja aseta ruuvit (C) ja aluslaatat (D, E) käsitukien alapäässä oleviin kiinnitysreikiin. Kiristä ruuvit huolellisesti.



Aseta mittari oikeaan asentoon. Kiristä ruuvit (C) ja aluslaatat (D) käsitukien yläpään kiinnitysreikiin.



VERKKOJOHTO

Ennen kuin kytket juoksumaton virtalähteeseen, tarkista jännitteen sopivuus laitteesi tyyppikilvestä. Kytke verkkovirtajohdon pistotulppa juoksumaton liittimeen.



TURVA-AVAIN

Juoksumatto ja käyttöliittymä toimivat vain, jos turvaavain on asetettu kunnolla paikalleen; laite pysähtyy välittömästi, kun turva-avain irtoaa. Aseta turva-avain paikalleen mittarin alaosaan ja kiinnitä turva-avaimen naru pidikkeen avulla vaatetukseesi, esim. kaulukseen tai rintapieleen. Varmista harjoitellessasi, että turva-avaimen pidike on kiinnitetty vaatetukseesi kunnolla; turva-avaimen narun kiristyessä pidike ei koskaan saa irrota vaatetuksestasi ennen kuin turva-avain on irronnut käyttöliittymästä. Ota tukea käsituesta aina kun nouset matolta pois. Älä hyppää liikkuvalta matolta.

YLEISTÄ HARJOITTELUSTA

Moottoroidun juoksumaton toimintoihin ja hallintaan tulee tutustua huolellisesti ennen harjoittelun aloittamista. Harjoittelu juoksumatolla on erinomaista aerobista liikuntaa, jonka perusideana on, että liikunta on sopivan kevyttä mutta pitkäkestoista. Aerobinen liikunta perustuu maksimaalisen hapenottokyvyn parantamiseen; se puolestaan lisää kestävyyttä ja kuntoa.

Aerobinen liikunta on ennen kaikkea miellyttävää. Hien pitää nousta pintaan, mutta syke ei saa nousta kohtuuttoman korkealle. Näin harjoitusta voidaan jatkaa pidempäänkin. Suositus harjoituksen pituudeksi on 30-60 minuuttia kolme kertaa viikossa tavoitteiden, kunnon ja mahdollisuuksien mukaan. Mikäli haluat harjoitella kävellen, voit lisätä suorituksen vaihtelevuutta ja vaativuutta muuttamalla juoksualustan kulmaa. Kävelyharjoitusta voi monipuolistaa myös harjoittamalla samanaikaisesti käsilihaksia pienillä painoilla. Huomioi tällöin tasapainosi ja muut turvallisuustekijät. Lisätietoja Tunturin kuntolaitteista sekä harjoittelusta löydät internetistä Tunturin kotisivuilta www.Tunturi.com.

HUOMIOITAVAA HARJOITTELUPAIKASTA

- Laitetta saa käyttää vain sisätiloissa.
- Sijoita juoksumatto kovalle, tasaiselle ja suojatulle alustalle. Valitse laitteen sijoituspaikka siten, että laitteen eteen ja sivuille jää vähintään 100 cm ja taakse 100x200 cm vapaata tilaa. Huolehdi, etteivät lapset tai kotieläimet tule tälle alueelle laitetta käytettäessä.
- Huolehdi, että harjoitteluympäristö on riittävän hyvin ilmastoitu. Vilustumisen estämiseksi vältä kuitenkin harjoittelua vetoisissa tiloissa.

HUOMIOITAVAA LAITTEEN KÄYTÖSTÄ

- Mikäli lasten annetaan käyttää laitetta, vanhempien tai muiden vastuullisten tulee ottaa huomioon lasten sekä henkinen että fyysinen kehitys ja ennen kaikkea luonne. Lapsia tulee valvoa ja opastaa juoksumaton oikeassa käytössä.
- Vain yksi henkilö kerrallaan saa harjoitella laitteella.
- Pidä kätesi kaukana liikkuvasta matosta. Pidä laitteen alusta aina tyhjänä äläkä työnnä sinne käsiäsi tai jalkojasi tai mitään esineitä.
- Käytä harjoitellessasi sopivaa vaatetusta ja asianmukaisia jalkineita. Varmista, että kengännauhasi ovat harjoitellessa aina kunnolla solmitut.

Käytä vain sisäkäyttöön tarkoitettuja urheilujalkineita.
- Varmista ennen harjoittelun aloittamista, että laite on kaikin puolin kunnossa. Älä koskaan käytä viallista laitetta.
- Älä käytä laitetta mikäli kaikki katteet ja suojukset eivät ole paikoillaan.
- Älä milloinkaan jätä mattoa pyörimään ilman valvontaa.

HARJOITUKSEN ALOITTAMINEN

- Muista venytellä sekä harjoituksen alussa että lopussa. Venyttelyn avulla saat lihaksesi ja nivelsiteesi joustaviksi, laukaiset mahdolliset jännitystilat ja vältät venähdykset ja kipeytymiset harjoituksen aikana. Tee liikkeet rauhallisesti, pitkään ja nykimättä.
- Käynnistä juoksumatto harjoitusta varten aina siten, että seisot hajareisin juoksumaton reunalevyillä.
- Aloita harjoitus hitaalla nopeudella, ja lisää nopeutta ja/tai kulmaa asteittain kuntosi ja tuntemustesi mukaan.
- Ota tukea käsituesta aina kun nouset matolle tai siltä pois ja aina kun vaihdat maton nopeutta kesken juoksun. Älä hyppää liikkuvalta matolta.
- Pidä selkä ja niska suorana, näin vältät niskan, hartioiden ja selän puutumista ja kipeytymistä. Juokse aina mahdollisimman keskellä mattoa, ja pidä etäisyytesi mittariin sellaisena, ettei se häiritse juoksuasi, mutta yllät siihen helposti.
- Mikäli laitteen toiminnassa ilmenee häiriöitä harjoituksen aikana, ota käsituesta kiinni ja siirry välittömästi seisomaan hajareisin juoksumaton reunalevyille. Sammuta juoksumatto ja katso käyttöohjeen kohta Käyttöhäiriöt.
- Jos tunnet harjoittelun aikana pahoinvointia, huimausta tai muita epänormaaleja oireita, keskeytä harjoittelu välittömästi ja ota yhteys lääkäriin.

HARJOITUKSEN PÄÄTTÄMINEN

- Älä lopeta harjoitustasi yhtäkkiä, vaan vähennä nopeuttasi asteittain, äläkä unohda venyttelyä harjoituksen päätyttyä.
- Irrota turva-avain käyttöliittymästä.
- Kytke virta pois päältä POWER-painikkeesta.
- Irrota verkkojohto sekä virtalähteestä että juoksumatosta.
- Puhdista laite tarvittaessa hiestä hieman kostealla liinalla tai pyyhkeellä; älä käytä liuottimia.
- Säilytä verkkojohto lasten ulottumattomissa ja poissa kulkuväyliltä.

SYKE

Paras rasitustason mittari on oman sydämen syketaajuus. Lähde liikkeelle selvittämällä ensin maksimisykearvosi eli se lyöntimäärä, josta sykkeesi ei enää nouse, vaikka rasitus lisääntyisikin. Jos et tiedä omaa maksimisykearvoasi, voit käyttää seuraavaa kaavaa suuntaa antavana:

220 – IKÄ

Maksimisyke voi vaihdella yksilöllisesti runsaastikin. Maksimisyke putoaa keskimäärin yhden sykkeen vuodessa. Varsinkin siinä tapauksessa, että kuulut johonkin riskiryhmään, kannattaa sinun ehdottomasti varmistaa maksimisykkeesi lääkärin avustuksella. Olemme määritelleet kolme eri sykealuetta, joista löydät tavoitteitasi parhaiten vastaavat harjoittelualueet.

ALOITTELIJAN TASO:
50 - 60 % maksimisykkeestä
Tämä taso on sopiva laihduttajille, toipilaille ja niille, jotka eivät ole harrastaneet liikuntaa aikaisemmin tai pitkään aikaan. Suositeltava harjoitusmäärä on kolme kertaa viikossa vähintään puoli tuntia kerrallaan.

KUNTOILIJAN TASO:
60 - 70 % maksimisykkeestä
Tämä taso sopii erinomaisesti kunnon kohottamiseen ja ylläpitämiseen. Harjoituksen tulisi kestää kerrallaan vähintään puoli tuntia ja harjoituskertoja tulisi olla vähintään kolme viikossa. Mikäli haluat kohottaa kuntoasi edelleen, sinun on lisättävä joko harjoituskertoja tai harjoitustehoa (ei kuitenkaan molempia yhtäaikaa).

AKTIIVIKUNTOILIJAN TASO:
70 - 80 % maksimisykkeestä
Harjoittelu tällä tasolla soveltuu vain erittäin hyväkuntoisille ja edellyttää jo pitkään jatkunutta kuntoilua.

Käsituissa olevat antureihin mittaavat pulssia aina kun laitteen käyttäjä koskettaa molempia sensoreita yhtäaikaisesti. Luotettava pulssinmittaus edellyttää että iho on jatkuvassa kosketuksessa antureihin ja että sensoreita koskettava iho on hieman kostea. Liian kuiva ja liian kostea iho heikentävät käsipulssimittauksen toimivuutta. Huomaa myös, että mikäli harjoitellessa jalat iskeytyvät voimakkaasti mattoon, voi tästä aiheutua häiriöitä jotka puolestaan saattavat heikentää käsipulssimittauksen luotettavuutta. Käyttöturvallisuuden varmistamiseksi suosittelemme pulssinmittauksen käyttöä kävelyvauhtisessa harjoittelussa tai liikkumatta joko maton reunalevyillä seisten tai pysäyttämällä maton

MITTARI

PAINIKKEET

A. TURVA-AVAIN
Mittari ja juoksumatto ovat toimintavalmiina vain mikäli turva-avain on paikallaan SAFETY KEY -alueen päällä. Mittari ja juoksumatto pysähtyvät välittömästi, mikäli turva-avain siirretään paikaltaan.

B. PÄÄTOIMINTOPAINIKKEET
1. INCLINE +
a. Lisää tällä painikkeella juoksualustan kulmaa (0-10 %). Pidempi painallus nopeuttaa arvojen vaihtumista.
b. Valitse tällä painikkeella harjoitusohjelma.

2. INCLINE –
c. Vähennä tällä painikkeella juoksualustan kulmaa (10-0 %). Pidempi painallus nopeuttaa arvojen vaihtumista.
d. Valitse tällä painikkeella harjoitusohjelma.

3. START / STOP
Käynnistä ja lopeta valittu harjoitusohjelma.

4. enter / SELECT
e. Painamalla tätä painiketta vahvistat tekemäsi valinnan.
f. Painamalla tätä painiketta näyttö vaihtaa näyttötilaansa. Vaihtoehtoina TIME, INCLINE, PULSE, DISTANCE, CAL, SPEED.

5. SPEED +
g. Lisää tällä painikkeella maton nopeutta (0.8-16.0 km/h). Pidempi painallus nopeuttaa arvojen vaihtumista.
h. Valitse tällä painikkeella harjoitusohjelma.

6. SPEED -
i. Vähennä tällä painikkeella maton nopeutta (16.0-0.8 km/h). Pidempi painallus nopeuttaa arvojen vaihtumista.
j. Valitse tällä painikkeella harjoitusohjelma.

7. SPEED PIKAPAINIKKEET
Nopeudensäädön pikapainikkeiden arvot ovat 3, 6 ja 9 km/h. Pikapainikkeen avulla matto muuttaa kiihdyttää tai hidastaa painikkeen osoittamaan nopeuteen.

8. INCLINE PIKAPAINIKKEET
Juoksumaton kulman pikapainikkeiden arvot ovat 3, 6 ja 9 %. Pikapainikkeen avulla matto muuttaa kulmansa painikkeen osoittamaan arvoon.

NÄYTÖT

TIME (AIKA):
harjoitusaika välillä 00:00 – 99:59. Aseta aika + / - painikkeilla.

SPEED (NOPEUS):
maton kulkunopeus välillä 0.8 – 18.0 km/h. Säädä nopeutta SPEED + / - painikkeilla tai pikapainikkeilla.

DISTANCE (MATKA):
harjoitusmatka välillä 0.00 – 999 km. Aseta matka + / - painikkeilla.

CALORIES:
energiankulutus harjoituksen aikana välillä 0 – 9999. Aseta energiankulutustavoite + / - painikkeilla.

PULSE (SYKE):
harjoitussyke

INCLINE (KULMA):
harjoitussyke kulma välillä 0 - 12%.

LED TRACK:
10 LED = 0.4 km MATON KÄYTTÖ JA OHJELMAT

- Aseta turva-avain mittarin Safety key –kentän päälle.
- Paina POWER-painiketta. Mittari käynnistyy.
- Paina SELECT-painiketta ja valitse ohjelma.
- Ohjelmassa PRO1 (manuaaliharjoitus) näyttöön tulee juoksurata. Ohjelmassa PRO2-8 (valmisohjelma) näyttöön tulee harjoitusprofiili. Vahvista valintasi ENTER / SELECT-painikkeella.
- Ohjelmissa PRO1 ja PRO2-8, aseta haluamasi harjoituksen kesto + / - painikkeilla. Aika näkyy TIME-ikkunassa. Vahvista asetus ENTER / SELECT-painikkeella. Aloita harjoitus START-painikkeella. PRO1-ohjelmassa voit muuttaa säätöpainikkeiden avulla maton nopeutta ja kulmaa. PRO2-8:ssa nopeuden ja kulman muutokset ovat automaattisia, mutta voit säätää kutakin profiililpylvästä kulma- ja nopeussäätöpainikkeiden avulla.

HUOLTO

Laitteen käyttöturvallisuuden ylläpitäminen vaatii säännöllistä huoltoa ja mahdollisten toimintahäiriöitä aiheuttavien tekijöiden (osien kuluminen jne.) tarkkailua. Tarkista kerran vuodessa kaikkien kiinnitysruuvien ja muttereiden kireys. Mikäli jokin laitteen osa vikaantuu, osa tulee vaihtaa välittömästi. Laitetta ei saa käyttää ellei se ole täysin toimintakuntoinen.

JUOKSUMATON PUHDISTUS JA HUOLTOVOITELU

HUOLTOVOITELUN LAIMINLYÖNTI VOI JOHTAA TAKUUN RAUKEAMISEEN

Puhdista käsituet ja käyttöliittymä pölystä ja liasta säännöllisesti hieman kostealla kankaalla. Älä käytä liuottimia. Puhdista juoksumaton rungon näkyvät osat (mm. matto, pohjalevy, reunalevyt) pienisuuttimisella imurilla säännöllisesti. Laitteen pohjapuolen puhdistusta varten nosta juoksumatto säilytysasentoon. Pidä myös juoksumaton ympäristö puhtaana. Käytössä juoksumatto kerää esim. pölyä, joka voi aiheuttaa ongelmia laitteen toiminnassa.
Tavanomaisessa kotikäytössä (enimmäiskäyttöaika 1 tunti / päivä) juoksumaton voitelu tulee tarkistaa kerran kuukaudessa – matto tulee kuitenkin voidella vain silloin kun se on tarpeen. Vaativammassa käytössä voitelu tulee tarkistaa mainittua useammin. Helpointa tämä on tehdä ennen harjoituksen aloittamista. Tarkista voitelu seuraavasti:

- Varmista että juoksumatto on irroitettu virtalähteestä. Astu laitteen maton päälle ja seiso tukevasti siinä kohtaa, jossa normaalisti juokset matolla.
- Tartu poikittaiskäsitukeen ja työnnä mattoa jaloillasi edestakaisin. Maton tulee liukua pehmeän tasaisesti, ilman ääntä.
- Mikäli matto liikkuu nykivästi tai ei lainkaan, tarkista onko pohjalevyn pinnassa voiteluainetta työntämällä kätesi maton alle.

Voitele juoksualusta seuraavasti:

- Kiinnitä voiteluputki T-Lube S -purkin nokkaan.
- Nosta juoksumatto säilytysasentoon ja lukitse se.
- Työnnä voiteluputki aluslevyn ja maton väliin takatelan viereen laitteen alapuolelta siten, että voiteluputken pää on maton keskikohdalla.
- Ruiskuta voiteluainetta 2-3 sekunnin ajan.
- Laske juoksualusta alas käyttöasentoon. Aloita harjoituksesi tai anna maton pyöriä vähintään 5 minuutin ajan.

TÄRKEÄÄ!
Käytä pohjalevyn voiteluun vain Tunturin T-Lube S voiteluainetta. T-Lube S voiteluainetta sekä neuvoja juoksumaton huollosta ja voitelusta saat laitteesi myyjältä.

MATON KESKITTÄMINEN

Tarkkaile maton kulkua harjoittelusi aikana ja suorita alla esitetyt säätötoimet välittömästi, kun huomaat niihin tarvetta. Maton tulee kulkea laitteen keskellä. Keskittämistä ei yleensä tarvita, mikäli juoksumatto on tasaisella ja kovalla alustalla ja maton kireys on oikea ja matto on oikein keskitetty.

Esimerkiksi harjoittelijan epätasaisesta painonjakaumasta johtuen matto saattaa kuitenkin lähteä siirtymään kohti laitteen toista reunaa.

Säädä nopeudeksi 5 km/h.
Jos matto siirtyy kohti laitteen vasenta reunaa, käännä juoksumaton takareunassa olevaa vasemmanpuoleista säätöruuvia ¼ kierrosta myötäpäivään ja oikeanpuoleista säätöruuvia ¼ kierrosta vastapäivään. Jos matto siirtyy kohti laitteen oikeaa reunaa, käännä oikeanpuoleista säätöruuvia ¼ kierrosta myötäpäivään ja vasemmanpuoleista säätöruuvia ¼ kierrosta vastapäivään. Säätö on riittävä, mikäli matto pysyy keskellä, mutta jos matto jatkaa edelleen kulkemistaan kohti laitteen toista reunaa,

jatka asteittaista säätämistä kunnes matto kulkee suoraan.

Mikäli maton annetaan kulkea pidemmän ajan vinossa siten, että jompikumpi maton reuna hankaa laitteen sivuja vasten, laitteen käytössä saattaa ilmetä häiriöitä. Laitteen takuu ei korvaa maton keskittämisen laiminlyömisestä johtuvia vikoja tai vaurioita.

MATON KIREYDEN SÄÄTÖ

Maton tulee olla niin löysällä kuin mahdollista. Mattoa pitää kuitenkin kiristää, jos se normaalikäytössä alkaa luistaa telan päällä. Kireyden säätö suoritetaan samoilla säätöruuveilla kuin keskittäminen. Mikäli matto ei kiristy säätöruuveista, ota yhteys laitteen myyjään.

k. Säädä nopeudeksi 5 km/h.
l. Kierrä molempia säätöruuveja myötäpäivään ¼ kierrosta.
m. Yritä hidastaa maton kulkua kävelemällä jarruttaen, ikään kuin kulkisit alamäkeen.

Mikäli matto luistaa edelleen, kierrä vielä ¼ kierrosta ja toista kokeilu. Hyvin voimakkaasti jarrutettaessa matto saa luistaa. Mikäli matto luistaa jatkuvasti säädöistä huolimatta, ota yhteys laitteen myyjään.

KÄYTTÖHÄIRIÖT

Jatkuvasta laaduntarkkailusta huolimatta laitteessa saattaa esiintyä yksittäisistä komponenteista johtuvia yksilövikoja tai toimintahäiriöitä. Koko laitteen toimittaminen korjattavaksi on yleensä tarpeetonta, sillä vika on useimmiten korjattavissa ko. osan vaihdolla.
Mikäli laitteen toiminnassa ilmenee häiriöitä käytön aikana, ota välittömästi yhteys laitteen myyjään. Ilmoita laitteesi malli ja sarjanumero, sekä häiriön luonne, laitteen käyttöympäristö sekä ostopäivämäärä. Mikäli juoksumatossasi ilmenee normaalista poikkeavia toimintoja, sammuta laite POWER-painikkeesta ja odota minuutin verran. Käynnistä tämän jälkeen matto ja totea onko virhetoiminta poistunut. Mikäli virhetoimintoa ei enää esiinny, laitetta voi käyttää normaalisti. Mikäli virhetoiminto ei ole poistunut, ota yhteys laitteen myyjään.
Mikäli tarvitset laitteeseesi varaosia, ota yhteys laitteen myyjään. Ilmoita aina laitteen malli, sarjanumero sekä tarvittavan osan varaosanumero. Varaosaluettelon löydät tämän oppaan lopusta. Laitteessa saa käyttää vain varaosalistassa mainittuja osia.

VIRHEILMOITUKSET

Mittari antaa ilmoituksen havaitsemistaan toimintahäiriöistä.

E1: Nopeussensorihäiriö. Irrota verkkojohto virtalähteestä, odota minuutti ja käynnistä uudestaan. Mikäli virheilmoitus on poistunut, voit käyttää laitetta normaalisti. Mikäli virheilmoitus ei poistu, ota yhteys laitteen myyjään.

E6, E7: Nostomoottorihäiriö. Irrota verkkojohto virtalähteestä, odota minuutti ja käynnistä uudestaan. Mikäli virheilmoitus on poistunut, voit käyttää laitetta normaalisti. Mikäli virheilmoitus ei poistu, ota yhteys laitteen myyjään.

YLIVIRTASUOJA

Mikäli juoksumaton virrankulutus kasvaa liian suureksi, maton ylivirtasuoja katkaisee virransyötön juoksumatolle ja sulakkeen painike hyppää ylös. Toimi tällöin seuraavasti:
Irrota laite virtalähteestä. Tarkista erityisesti maton voitelu sekä mahdolliset muut mekaaniset syyt ylivirtasuojan laukeamiseen.
Paina sulakkeen painike alas.
Liitä laite virtalähteeseen. Laite on jälleen valmis käytettäväksi.



TÄRKEÄÄ!
Älä paina sulakkeen painiketta alas ennen kuin olet irrottanut virtajohdon juoksumatosta!

Mikäli sammutat mittarin mutta jätät laitteen virtalähteeseen kytketyksi, virta kulkee yhä mittarille. Mittarissa on varmuustoimenpiteenä turvaohjelma, joka sulkee virrankulun matolle, mikäli laitetta ei käytetä kuuden tunnin aikana. Mikäli juoksumatto on sammuttanut itsensä, käynnistä laite seuraavasti:

- Irrota virtajohto juoksumaton liittimestä.
- Kiinnitä virtajohto laitteen liittimeen ja käynnistä laite.

KULJETUS JA SÄILYTYS

Käyttökuntoon asennetun juoksumaton voi taittaa tilaa säästävään säilytysasentoon.

TÄRKEÄÄ!
Juoksualustan voi nostaa säilytysasentoon vain mikäli alustan kulma on 0% mikäli kulma on jokin muu, säilytysasentoon nostaminen vahingoittaa lukitusmekanismia! Nosta juoksualustaa ylös kunnes se lukittuu.

TÄRKEÄÄ!
Juoksualustan lukittuessa kuulet naksahtavan äänen.

TÄRKEÄÄ!
Laitteen rakenne laskee juoksualusta alas hitaasti. Varmista aina että tila juoksualustan alla on tyhjä ennen alustan laskemista.
Varmista aina ennen laitteen siirtämistä, että virtajohto on irti niin laitteesta kuin virtalähteestäkin. Nosta juoksualusta ylös niin että se lukittuu. Siirrä juoksumattoa siirtopyörien varassa, ohjaa mattoa käsituesta kiinni pitäen. Laske juoksualusta saattaen lattialle.

TÄRKEÄÄ!
Siirrä juoksumattoa erityisellä varovaisuudella lattian epätasaisuuksien, esim. kynnysten yli. Rapuissa mattoa tulee aina kantaa. Suosittelemme, että käytät suojaavaa alustaa, kun laitetta siirretään.

TÄRKEÄÄ!
Matto on tarvittaessa keskitettävä laitteen siirtämisen jälkeen.
Säilytä laite mahdollisimman kuivassa ja tasalämpöisessä paikassa pölyltä suojattuna. Irrota verkkopistoke jokaisen käyttökerran jälkeen.





Avaaminen
Paina kevyesti jalalla teleskooppiputken keskiosasta vapauttaaksesi lukitusmekanismin. Tämän jälkeen saat laskettua juoksualustan.



TEKNISET TIEDOT

Pituus (säilytysasento)... 174 cm (93 cm)
Korkeus ..... 138 cm (152 cm)
Leveys .....78 cm
Paino .....67 kg
Juoksupinta-ala .....43 x 137 cm
Nopeus ..... 0,8-16 km/h
Kaltevuuden säätö.....0-10 %
Moottori.....2 hv

Tämä Tunturi-laite täyttää sähkömagneettista yhteensopivuutta koskevan EU:n EMC-direktiivin (89/336/EEC) sekä pienjännitedirektiivin (73/23/EEC) vaatimukset. Tuote on varustettu sen mukaisesti CE-merkinnällä. Jatkuvan tuotekehityksen vuoksi oikeudet muutoksiin pidätetään.

TÄRKEÄÄ!
Tässä ohjekirjassa annettuja tietoja kuntolaitteen asennuksesta, käytöstä ja huollosta tulee noudattaa erittäin huolellisesti. Takuu ei korvaa vahinkoja, jotka ovat aiheutuneet tässä ohjekirjassa mainittujen asennus-, säätö- tai huoltotoimenpiteiden laiminlyönneistä. Mikäli asennus-, säätö- tai huoltotoimenpiteitä tehdään toisin kuin ohjekirjassa mainitaan tai laitteelle tehdään toimenpiteitä, joita Tunturi ei nimenomaisesti ole hyväksynyt, laitetta ei tule käyttää!

Toivotamme Sinulle miellyttäviä harjoitushetkiä Tunturi-harjoituskumppanisi kanssa!

PROFILES

Step	Prog. 2	Prog. 3	Prog. 4	Prog 5.	Prog 6.	Prog. 7	Prog 8.
	Rolling hills	Weight loss	Mountain	Random	Intervals	Plateau	Ramp
	incline	incline	incline	incline	speed	speed	speed
1	1	1	1	1	2.0	3.0	2.0
2	2	3	2	2	5.0	5.0	3.0
3	1	5	3	1	3.0	6.0	4.0
4	3	6	5	4	6.0	7.0	5.0
5	1	4	6	2	3.0	6.0	5.0
6	4	6	5	5	6.0	5.0	6.0
7	1	7	5	1	3.0	7.0	7.0
8	4	6	3	2	7.0	6.0	8.0
9	2	5	1	3	5.0	5.0	6.0
10	1	4	1	1	2.0	2.0	3.0



PARTS LIST

Buble	Description	Qty
1	Console base	1
2	Handlebar, LH	1
3	Handlebar, RH	1
4	Shock	1
5	Frame	1
6	Switch bracket	1
7	Front roller	1
8	Rear roller	1
9	Incline structure frame	1
10	Front support frame	1
11	Safety Key	1
12	Console left	1
13	User interface	1
14	Console right	1
15	Toggle switch LH (Elevation)	1
16	Toggle switch RH (Speed)	1
17	Hand pulse set	1
19	Handle grip	2
20	End cap	2
21	Main wire set	1
23	Anti-slip mat	2
24	Side landing	2
25	Running belt,	1
26	Running deck,	1
28	Overcurrent protector, 6A	1
29	Power socket	1
30	Power cable	1
31	ON/OFF switch	1
32	Motor, 1.25 HP DC/ 180V	1
33	Lift motor	1
34	Drive belt	1
35	Wire holder	2
36	Motor cover bracket	6
37	Speed sensor 1000MM	1
38	Rubber bumper, 22*17*6mm	8
39	Rear end cap, LH	1
40	Rear end cap, RH	1
41	Wheel, rubber 50	4
42	Frame end cap, front	2
43	Wheel, plastic 38	2
44	Front support cover, LH	1
45	Front support cover, RH	1
46	Front support end cap	2
47	Wheel cover	2
52	Power board	1
53	Ferrite	2
54	Wire holder	2
55	Plastic fixer	5
56	Power Wire Set	1
59	Transformer, EUR	1
60	Rubber rectangular mat	2
61	Rubber round mat	2
62	Motor cover	1
63	Through-leading rubber	1
64	Filter, EUR	1
65	Screw	19
66	Screw	6
67	Washer	4
68	Haxagon Screw	6
69	Hexagon Screw	2
70	Nylon Nut M8	10
71	Screw	24
72	Star washer	3
73	Fixing guide set	6
74	Screw	10
75	Plastic washer	10
76	Screw	2
77	Nyloc nut M10	7
78	Hexagon Screw	1
79	Screw	8
80	Hexagon Screw	3
81	Washer	5
82	Hexagon Screw	2
83	Fixing tube	2
84	Washer	4
85	Hexagon Screw	2
86	Star washer	2
87	Hexagon Screw	2
88	Washer	3
89	Fixing tube	2
90	Hexagon Screw	2
91	Hexagon Screw	2
92	Screw	9
93	Plastic washer	20
94	Screw	2
95	Hexagon Screw	1
96	Hexagon Screw	2
97	Hexagon Screw	2
98	Screw	2

EXPLODED VIEW



TUNTURI®

www.tunturi.com

Tunturi New Fitness B.V.
P.O. Box 60001
1320 AA
The Netherlands

www.tunturi.com